


Operating Instructions INTORQ BFK466-12

Segment spring-applied brake




INTORQ

setting the standard

www.intorq.de

Product key

INTORQ B FK 466 - 12



Legend for the INTORQ BFK466 product key

A	Product group	Braking
B	Product family	Spring-applied brake
C	Type	466
D	Size	12

Not coded: Supply voltage, hub bore, options

Nameplate

Field	Content			Example
1	Manufacturer	CE mark		
2	Brake type	Model identification		
3	Rated voltage	Rated power	Desired customer no.	
4	Order no.	Friction force	Date of manufacture	

Packaging sticker

Field	Content				Example
1	Manufacturer	Bar code of no.			
2	Designation	Order no.			
3	Type see product key	Qty per box			
4	Rated voltage	Rated power	Friction force	Date of packaging	
5	Model identification	Desired customer no.			
6	Supplement	CE mark			

Document history

Material number	Version			Description
13313979	1.0	08/2009	TD09	First edition

i Contents

1	Preface and general information	5
1.1	About these Operating Instructions	5
1.2	Terminology used	5
1.3	Scope of supply	5
1.4	Labelling	6
1.5	Legal regulations	6
2	Safety instructions	7
2.1	General safety information	7
2.2	Notes used	9
3	Technical data	10
3.1	Product description	10
3.2	Rated data	11
3.3	Operating times	12
3.4	Operating frequency / friction work	13
3.5	Emission	14
4	Mechanical installation	15
4.1	Necessary tools	15
4.2	Mounting	15
4.3	Installation	16
5	Electrical installation	17
5.1	Electrical connection	17
6	Commissioning and operation	19
6.1	Functional test	19
6.2	During operation	21
7	Maintenance/repair	22
7.1	Wear of spring-applied brakes	22
7.2	Inspections	23
7.3	Maintenance operations	25
7.4	Spare parts order	25
8	Troubleshooting and fault elimination	26
9	Disposal	28

1 Preface and general information

1.1 About these Operating Instructions

- These Operating Instructions will help you to work safely on and with the multi-pole spring-applied brake. They contain safety instructions that must be followed.
- All persons working on or with the multi-pole spring-applied brake must have these Operating Instructions available and observe the information and notes relevant for their work.
- The Operating Instructions must always be in a complete and perfectly readable condition.

1.2 Terminology used

Term	In the following text used for
Spring-applied brake	Multi-pole spring-applied brake
Drive system	Drive systems with spring-applied brakes and other drive components

1.3 Scope of supply

- The spring-applied brakes are delivered preassembled, the brake disc is not included in the scope of supply.
- After receipt of the delivery, check immediately whether the items delivered match the accompanying papers. INTORQ does not accept any liability for deficiencies claimed subsequently. Claim
 - visible transport damage immediately to the forwarder.
 - visible deficiencies / incompleteness immediately to INTORQ GmbH & Co. KG.

1 Preface and general information

1.4 Labelling

Drive systems and drive components are clearly labelled and defined by the indications on the nameplates.

Manufacturer: INTORQ GmbH & Co KG, Wülmser Weg 5, D-31855 Aerzen

1.5 Legal regulations

Liability

- The information, data and notes in these Operating Instructions met the state of the art at the time of printing. Claims referring to drive systems which have already been supplied cannot be derived from the information, illustrations and descriptions.
- We do not accept any liability for damage and operating interference caused by:
 - inappropriate use
 - unauthorised modifications to the drive system
 - improper working on and with the drive system
 - operating faults
 - disregarding these Operating Instructions

Warranty

- Terms of warranty: see terms of sale and delivery of INTORQ GmbH & Co. KG.
- Warranty claims must be made to INTORQ immediately after detecting defects or faults.
- The warranty is void in all cases where liability claims cannot be made.

2 Safety instructions

2.1 General safety information

- These safety notes do not claim to be complete. If any questions or problems occur, please contact INTORQ GmbH & Co. KG.
- The spring-applied brake met the state of the art at the time of delivery.
- The spring-applied brake endangers persons, the spring-applied brake itself and other properties of the user if
 - unqualified personnel work on and with the spring-applied brake.
 - the spring-applied brake is used inappropriately.
- The spring-applied brakes must be planned in such a way that if they are correctly installed and used for their designed purpose in fault-free operation, they fulfil their function and do not put any persons at risk. This also applies to the interaction thereof with the overall system.
- Make sure by appropriate measures that in case of failure of the spring-applied brake no material damage is caused.
- Do not operate the spring-applied brake unless it is in perfect condition.
- Retrofitting, modifications and changes of the drive system are generally forbidden. In any case, INTORQ GmbH & Co. KG must be contacted beforehand.
- The friction lining and the friction surfaces must by no means have contact to oil or grease since even small amounts reduce the braking torque considerably.
- The braking torque will usually not be influenced if the brake is used under the environmental conditions that apply to IP54. Because of the numerous possibilities of using the brake, it is however necessary to check the functionality of all mechanical components under the corresponding operating conditions.

2 Safety instructions

2.1.1 Personnel responsible for safety

Operator

- An operator is any natural or legal person who uses the spring-applied brake or on whose behalf the spring-applied brake is used.
- The operator or his safety personnel must ensure
 - that all relevant regulations, notes and laws will be complied with,
 - that only qualified personnel will work on and with the drive system,
 - that the Operating Instructions will be available to the personnel working on and with the brake at all times,
 - that unqualified personnel will not be allowed to work on and with the spring-applied brake.

Skilled personnel

Skilled personnel are persons who - because of their education, experience, instructions, and knowledge about corresponding standards and regulations, rules for the prevention of accidents, and operating conditions - are authorised by the person responsible for the safety of the plant to perform the required actions and who are able to recognise potential hazards. (See IEC 364, definition of skilled personnel)

Application as directed

- Drive systems
 - are intended for use in machinery and systems.
 - must only be used for the purposes ordered and confirmed.
 - must only be operated under the ambient conditions prescribed in these Operating Instructions.
 - must not be operated beyond their corresponding power limits.

Any other use shall be deemed inappropriate!

Possible applications of the INTORQ spring-applied brake

- No explosive or aggressive atmosphere.
- Humidity, no restrictions.
- Ambient temperature -20°C to +40°C.
- With high humidity and low temperatures
 - Take measures to protect armature plate and rotor from freezing.
- Protect electrical connections against contact.


2 Safety instructions

2.2 Notes used

The following pictographs and signal words are used in this documentation to indicate dangers and important information:

Safety instructions




Structure of safety instructions:

 **Danger!**
 Characterises the type and severity of danger




Note
 Describes the danger

Possible consequences:
 ■ List of possible consequences if the safety instructions are disregarded.

Protective measure:
 ■ List of protective measures to avoid the danger.

Pictograph and signal word	Meaning
 Danger!	Danger of personal injury through dangerous electrical voltage Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken.
 Danger!	Danger of personal injury through a general source of danger Reference to an imminent danger that may result in death or serious personal injury if the corresponding measures are not taken.
 Stop!	Danger of property damage Reference to a possible danger that may result in property damage if the corresponding measures are not taken.

Application notes

Pictograph and signal word	Meaning
 Note!	Important note to ensure troublefree operation
 Tip!	Useful tip for simple handling
	Reference to another documentation

3 Technical data

3.1 Product description




Fig. 1 Design of an INTORQ BFK466-12 spring-applied brake with noise reduction

1	Stator	5	Compression spring	9	Microswitch
2	Brake disk	6	Cheese head screw	10	Terminal box
3	Flange	7	Guide sleeve	11	Friction lining
4	Armature plate	8	Cheese head screw	12	Support of friction lining

3.1.1 General information

The INTORQ BFK466 spring-applied brake is designed as a floating caliper brake for mounting on direct drive motors. The brake disk (2) is not included in the scope of supply. By using two or more spring-applied brakes on one brake disk, the demand for redundancy can be fulfilled for special applications such as lift and stage technology.

The braking torque is generated by the pressure of several compression springs (5) via friction locking between the two friction linings (11) of the armature plate (12) and the flange (3) and the brake disk (2). The brake is released electromagnetically. The suitable switching device rectifies the supply voltage (AC voltage) and decreases it after a short time when the brake is released. Thus, the medium electrical brake power is reduced. As an option, the switching device can be installed into the terminal box (10).

The INTORQ BFK466 spring-applied brake is designed for converting mechanical work and kinetic energy into heat energy. Thanks to the static breakaway torque, loads can be held at standstill.

Emergency braking at higher speeds is possible. Here, the maximum permissible speed (see chapter 3.2) must not be exceeded.

The stator (1) is designed to be of thermal class F. The limit temperature of the coils is 155°C.

The spring-applied brake is designed for a maximum operating time of 60%.

3 Technical data

3.1.2 Braking

During braking, the support of the friction lining (12) and the affixed friction lining (11) are pressed against the axially fixed brake disc (2). Nearly at the same time, the caliper moves on the guide sleeves (7) in the opposite direction, so that the friction lining (11) on the flange (3) is pressed against the brake disc, too. The braking torque is supported by the mounting flange via the guide sleeves (7). The asbestos-free friction linings ensure a high braking torque with low wear.

3.1.3 Brake release

When the brake is applied, there is an air gap "sair" between the armature plate (4) and the pole faces of the stator (1). To release the brake, the respective switching device supplies the coils of the stator (1) with the overexcitation voltage. The resulting magnetic force draws the armature plate (4) against the spring force towards the pole faces of the stator (1). Now, the spring force is taken from the support of the friction lining (12). The caliper can move on the guide sleeves (7) until the brake disk (2) is relieved and can rotate freely. After approx. 1...2 seconds, the supply voltage is decreased to 50%.

3.1.4 Release monitoring

The INTORQ BFK466 spring-applied brake is equipped with a microswitch (changeover contact) which monitors the switching status. During brake release, the microswitch (9) changes over. This must exclude drive operation against the applied brake.

3.2 Rated data

Type	Friction force	Brake disk radius	Max. sliding speed	Voltage ¹⁾ , ³⁾	Power ²⁾	Coil resistance	Max. current	Overexcitation time
	F_R [N]	R_a [mm] min./max.	$V_{max.}$ [m/s]	$U \pm 10\%$ [V] DC	P_{20} [W]	$R_{20 \pm 5\%}$ [Ω]	$I_{max.}$ [A]	sec.
INTORQ BFK466-12	1172	250/500	9.65	205/103	367/92	114.5	1.79	1...2

Type	Air gap	Max. air gap	Fixing screws	Tightening torque	Max. perm. switching energy	Transition operating frequency	Weight (without brake disk)
	$s_{Lü \text{ nom.}}$ [mm]	$s_{air \text{ max.}}$ [mm]		M_a [Nm]	Q_E [J]	S_{fo} [h ⁻¹]	m [kg]
INTORQ BFK466-12	0.4±0.1	0.8	2 x M10 - 10.9	46	15000	38	7.5

1) Voltage for releasing / holding

2) Coil power at 20°C when releasing / holding

3) With 230 V AC rectifier installed in terminal box

3 Technical data

3.3 Operating times




Fig. 2 Operating times of the INTORQ spring-applied brakes

- t_1 Engagement time
- t_2 Disengagement time (up to $M = 0.1 M_r$)
- t_{11} Reaction delay during engagement
- t_{12} Rise time of the braking torque

Type	Operating times [ms] at $s_{airrated}$			
	Engaging			Disengaging
	t_{11}	t_{12}	t_1	t_2
INTORQ BFK466-12	12	18	30	50

Tab. 1 Switching energy - operating frequency - operating times

The transition from the state without brake torque to the steady brake torque is not without delay. The engagement times are valid for switching on the DC side with an induction voltage of approx. 5 to 10 times nominal voltage. The chart shows the delay during engagement t_{11} , the rise time of the brake torque t_{12} and the engagement time $t_1 = t_{11} + t_{12}$, as well as the disengagement time t_2 .

Disengagement time

The disengagement time is not affected by DC or AC switching. The indicated disengagement time applies to an air gap of 0.4 mm. When the air gap is larger (as a result of wear), the disengagement time increases.

Engagement time

Short brake engagement times are vital for emergency braking. DC switching together with a suitable spark suppressor must therefore be provided.

If the drive system includes a frequency inverter so that the brake is deenergised only when the motor is at standstill, switching on the AC side is also possible (not valid for emergency braking). In this case, engagement times will be 5 times longer.

3 Technical data

3.4 Operating frequency / friction work




Fig. 3 Switching energy as a function of the operating frequency

$$S_{fperm} = \frac{-S_{fo}}{\ln\left(1 - \frac{Q}{Q_E}\right)} \quad Q_{perm} = Q_E \left(1 - e^{-\frac{-S_{fo}}{S_f}}\right)$$

The permissible operating frequency " S_{fperm} " depends on the friction work " Q " (see Fig. 3). At a preset operating frequency " S_f ", the permissible friction work is " Q_{perm} ".

For " S_{fo} " and " Q_E ", please see chapter 3.2.

3 Technical data

3.5 Emission

Heat

Since the brake converts kinetic energy as well as mechanical and electrical energy into heat, the surface temperature varies considerably, depending on the operating conditions and possible heat dissipation. Under unfavourable conditions, the surface temperature can reach 130°C.



Danger!

Risk of burns on brake and brake disc!

Noises

The switching noise during engagement and disengagement varies depending on the air gap "s_{air}" and the brake size. It is between approx. 50 and 55 dB [A].

Others

Abrasion due to braking occurs in the form of dust.

In case of high load, the friction face will become so hot that odours may occur.





4 Mechanical installation






Stop!

■ Do not lubricate the screws with oil or grease.

4.1 Necessary tools

Type	Torque wrench	Insertion for hexagon socket screws	Transport screw	Crosstip screwdriver
				
	Measuring range [Nm]	Spanner width [mm]	Spanner width [mm]	Crosstip size
INTORQ BFK466-12	120	8 x 1/2" square	4 x 1/4" square	2

Feeler gauge	Caliper gauge	Multimeter
		

4.2 Mounting

4.2.1 Preparation

1. Unpack spring-applied brake.
2. Check for completeness.
3. Check nameplate data, especially rated voltage.

4 Mechanical installation

4.3 Installation



Stop!

The transport protection may differ depending on the type of brake.

The brake is delivered preassembled with two transport screws (1).

1. Position the brake radially over the brake disk (3).
2. Insert the mounting screws (2) and tighten them with the torque given (chapter 3.2).



Stop!

The sum total of the distances measured must not exceed " s_{airmax} "!

3. Remove the transport screws (1).
- Brake **without** emergency manual release
 - Remove transport screws (1) Fig. 4.
- Brake **with** emergency manual release
 - Undo lock nut and slacken transport screw (6) Fig. 4, until screw is approx. 1 mm from the stator.
 - Re-tighten lock nut
4. Switch the current on and off several times, checking the movability of the brake on the guide sleeves.
5. Check the clearance of the brake disk and the air gap " s_{air} " between the two friction linings (5) and the brake disk (3) with a feeler gauge (6).




Fig. 4 Installation of the INTORQ BFK466-12 spring-applied brake with and without manual release

5 Electrical installation

5.1 Electrical connection



Danger!

- Perform electrical connection only when no voltage is applied.
- If an "emergency stop" is carried out without the protective circuit provided, the control device may be destroyed. Observe the correct polarity of the protective circuit!



Note!

The suppressor circuit is already included in the INTORQ BEG-561-255-130 switchgear.




Fig. 5 INTORQ BFK466 connection diagram (circuit proposal for switching on the DC side)

Switch on

- K2 must be closed before K1!

Switch off

- Normal - AC switching
 - K2 remains closed
 - Open K1
- Emergency stop - DC switching
 - K1 and K2 are opened at the same time

bl blue
gr grey
bk black

5 Electrical installation

Pin assignment for microswitch




Fig. 6 INTORQ BFK466 terminal box (optional with integrated switching device)

Microswitch:	Input connection	black
	NO contact	blue connection
	NC contact	grey connection

When current is fed to the spring-applied brake, the armature plate is released. The microswitch is actuated and outputs the “Spring-applied brake released” signal.



Note!

Application range recommended for the microswitch

- DC current: 10 mA to 100 mA at 12 V
- AC current: 10 mA to 5 A at 12 V / max. 250 V

Earthing

Earthing must be provided via an earthing screw in the terminal box (Fig. 6) or via an M4 thread in the stator.



Note!

PE connection via the fixing screws on the motor is not permitted because there is no electrically conductive connection between the brake and the guide sleeves!

Temperature sensor connection (optional)

The spring-applied brake can be delivered with PTC sensors according to DIN 44082 for temperature monitoring (reference temperature 130°C). The signal is evaluated via a PTC thermistor tripping device provided by the customer.

Connection: AWG 26 blue/blue

6 Commissioning and operation

6.1 Functional test

**Danger!**

The brake must be free of residual torque. The motor must not rotate.

**Danger!**

Live connections must not be touched.

In the event of failures, refer to the troubleshooting table in chapter 8. If the fault cannot be eliminated, please contact the aftersales service.

6.1.1 Release / voltage check

1. Remove two bridges from the motor terminals. Do not switch off the voltage supply for the brake.
2. Measure the AC voltage at the motor terminals. It must be zero!
3. Switch on the current for the brake.
4. Measure the AC voltage at the motor terminals. It must be equal to the mains voltage!
5. Starting at the stator's side, move the brake toward the brake disk until the friction lining carrier is fully placed on the armature plate and the friction lining is on the brake disk.
6. Check the air gap " s_{air} " between the brake disk and the friction lining at the flange end. It must amount to 0.4 ± 0.1 mm. The brake disk must rotate freely!
7. Switch off the power supply.
8. Screw the bridges onto the motor terminals.

6 Commissioning and operation

6.1.2 Manual release



Stop!

This operational test is to be carried out additionally!


The installed manual release is designed for operation using a Bowden cable. The support at the spring-applied brake is used to suspend the Bowden cable. If no Bowden cable is being used, the lever must be extended to a total length of approx. 800 mm.



Danger!

The brake must be free of residual torque. The motor must not rotate.

1. Pull lever with approx. 800 N (approx. 200 N with extension) until considerable increase in resistance is felt.
2. The rotor must be freely rotatable. A low residual torque is permissible.
3. Release the lever.



6 Commissioning and operation


6.1.3 Microswitch

Checking the release monitoring



Note!

The brake is deenergised, the transport screws are removed.



- 1 Hexagon head cap screw
- 2 Microswitch tappet

Check the setting of the microswitch for release monitoring using a feeler gauge with thickness "Y_{max.} and Y_{min.}" between hexagon head cap screw (1) and microswitch tappet (2).

Feeler gauge thickness	NC contact	NO contact
Y _{max.} = s _{air} - 0.10	Opened switch	Closed switch
Y _{min.} = s _{air} - 0.20	Closed switch	Opened switch

6.2 During operation

- Check the brake regularly during operation. Take special care of:
 - unusual noises and temperatures
 - loose fixing elements
 - the state of the cables.
- In the event of failures, refer to the troubleshooting table in chapter 8. If the fault cannot be eliminated, please contact the aftersales service.

7 Maintenance/repair

7.1 Wear of spring-applied brakes

INTORQ spring-applied brakes are wear-resistant and designed for long maintenance intervals. The friction lining and the mechanical brake components are subject to function-related wear. For safe and trouble-free operation, the brake must be checked and readjusted at regular intervals, and, if necessary, be replaced.

The following table describes different causes of wear and their effects on the components of the spring-applied brake. For calculating the service life of rotor and brake and determining the maintenance intervals to be observed, the relevant factors of influence must be quantified. The most important factors are the friction work, initial speed of braking and the operating frequency. If several of the causes of wear indicated for the friction lining occur in an application at the same time, the influencing factors must be added for calculating the wear. The INTORQ Select dimensioning program can be used to calculate the maintenance intervals.

Component	Cause	Effect	Influencing factors
Friction lining	Braking during operation	Wear of friction lining	Friction work
	Emergency stops		
	Overlapping wear during start and stop of drive		
	Active braking via the drive motor with support of brake (quick stop)		
	Starting wear in case of motor mounting position with vertical shaft, even when the brake is not applied		
Brake disc	Rubbing of brake lining	Brake disc is run in	Friction work
Guide sleeve	Relative movements and shocks between brake and guide sleeve	Wear of guide sleeve and friction bearing bushes	Number of start/stop cycles
Support of armature plate	Changing load cycles and shocks in backlash on reversal between armature plate and pins	Play of armature plate and pins	Number of start/stop cycles, braking torque
Springs	Axial load cycle and shear stress of springs through radial backlash on reversal of armature plate	Reduced spring force or fatigue failure	Number of switching operations of brake

7 Maintenance/repair

7.2 Inspections

For safe and trouble-free operation, the spring-applied brakes must be checked and maintained at regular intervals. On the plant side, the service costs can be reduced by a good accessibility of the brakes. This is to be considered when integrating the drives into the system and installing the system.

For working brakes, the maintenance intervals mainly result from the brake load in the application. When the maintenance intervals are calculated, all causes of wear must be considered (see chapter 7.1). For brakes with low brake loads, e.g. holding brakes with emergency stop, we recommend regular inspections at fixed intervals. To reduce costs, the inspections can be carried out together with other cyclic maintenance works for the system, if necessary.

If the brakes are not maintained, failures, production losses or damage to the system may occur. Therefore, a maintenance concept adapted to the particular operating conditions and brake loads must be defined for every application. For the INTORQ spring-applied brakes, the maintenance intervals and maintenance operations listed in the below table must be provided. The maintenance operations must be carried out as described in the detailed descriptions.

Type INTORQ BFK466-12	Time interval	
	for service brakes:	for holding brakes with emergency stop:
	<ul style="list-style-type: none"> ■ according to service life calculation ■ or else every six months ■ after 4000 operating hours at the latest 	<ul style="list-style-type: none"> ■ at least every two years ■ after 1 m cycles at the latest
	Maintenance	
Inspections if brake is built-on:	Inspections after brake has been removed:	
<ul style="list-style-type: none"> ■ Check release and control functions (see chap. 6.1.1) ■ Measure air gap (adjust if necessary, see chap. 4.3) ■ Thermal damages of the friction linings or the brake disk 	<ul style="list-style-type: none"> ■ Breaking out of the torque support at the sleeve bolts and the armature plate ■ Check springs for damage ■ Check brake disk and friction linings <ul style="list-style-type: none"> - Evenness > 0.1 mm - Max. run-in depth = Rated air gap of the size 	



Note!

Brakes with defective components or fixings must be replaced completely. In general, the following must be observed when carrying out inspection or maintenance work:

- Contamination due to oils and grease must be removed using cleaning agents suitable for brakes. Replace the brake if necessary after the cause of the defect has been identified. Pollution and dust in the air gap between stator and armature plate put trouble-free operation at risk and must be removed.
- After replacing the friction parts, the original braking torque will not be reached until the run-in operation of the friction surfaces has been completed. After replacing the friction parts, run-in counter friction faces have an increased initial rate of wear. In this case, adjust the air gap at an early stage if necessary.

7 Maintenance/repair

7.2.1 Braking torque / delay check



For important information, please see the Operating Instructions for the plant in which the brake is installed.



Danger!

Disconnect the drive from the load to prevent accidents. During the next inspection steps of the spring-applied brake, the motor must not run!

1. Switch on the current for the brake (see chapter 6.1.1).
2. Measure the air gap "s_{air}" between brake disc and friction lining with a feeler gauge (Fig. 4). The maximum permissible air gap "s_{air max.}" (see chapter 3.2) must not be exceeded! Readjust the air gap, if necessary (see chapter 4.3).



Stop!

If the maximum permissible air gap "s_{air max.}" (see chapter 3.2) is exceeded during operation, the braking torque may get lost!

3. Switch off the power supply.
4. Screw the bridges onto the motor terminals.

In case of drives with several brakes, one brake at a time can be released with the cheese head screws of the transport locking device when checking redundancy. The screws must be removed again after checking.



Stop!

The screws of the transport locking device must not be used for releasing the brake during evacuation!

7 Maintenance/repair

7.3 Maintenance operations

Under the operating conditions as a holding brake, the brake does not require any maintenance. Replacing the brake is made in reverse order of assembly (chapter 4.2).



Danger!

Disconnect the drive from the load to prevent accidents. During the next inspection steps of the spring-applied brake, the motor must not run!

1. Switch on the current for the brake or screw in the transport screws (M5x70 with washer).
2. Loosen the fixing screws at the guide sleeves (Fig. 4).
3. Remove the brake radially from the brake disk.
4. Switch off the power supply and disconnect the connecting cables.

7.4 Spare parts order

INTORQ BFK466spring-applied brake

Order quantity	_____ pcs.	
Size	<input type="checkbox"/> 12	
Voltage	<input type="checkbox"/> 103/52 V	<input type="checkbox"/> 205/103 V
Cable length	<input type="checkbox"/> Standard	
	_____ mm	(from 100 mm - 1000 mm in steps of 100 mm, from 1000 mm - 2500 mm in steps of 250 mm)
Terminal box mounted	<input type="checkbox"/>	
Manual release mounted	<input type="checkbox"/>	

Electrical accessories

Rectifier with overexcitation	<input type="checkbox"/>
--------------------------------------	--------------------------

8 Troubleshooting and fault elimination

If any malfunctions should occur during operation of the drive system, please check the possible causes using the following table. If the fault cannot be eliminated by one of the listed measures, please contact the aftersales service.

Error	Cause	Remedy
Brake cannot be released, air gap is zero	Coil is interrupted	<ul style="list-style-type: none"> ■ Measure coil resistance using multimeter: <ul style="list-style-type: none"> - Compare the measured resistance with the rated resistance (chapter 3.2). - Replace the brake when the resistance is too high.
	Coil has interturn fault or short circuit to ground	<ul style="list-style-type: none"> ■ Measure coil resistance using multimeter: <ul style="list-style-type: none"> - Compare the measured resistance with the rated resistance. The rated data is given in chapter 3.2. Replace the brake when the resistance is too low. ■ Test the coil for short circuit to ground using a multimeter: <ul style="list-style-type: none"> - Replace the brake in case of short circuit to ground. ■ Check the brake voltage (see defective rectifier, voltage too low).
	Defective or wrong wiring	<ul style="list-style-type: none"> ■ Check and correct the wiring. ■ Check the cable using a multimeter: <ul style="list-style-type: none"> - Replace the defective cable.
	Defective or wrong rectifier	<ul style="list-style-type: none"> ■ Measure the DC voltage at the rectifier using a multimeter. <p>When the DC voltage is zero:</p> <ul style="list-style-type: none"> ■ Measure the AC voltage at the rectifier. <p>When the AC voltage is zero:</p> <ul style="list-style-type: none"> - Switch on the voltage, - Check the fusing, - Check the wiring - Check the microswitch <p>When the AC voltage is OK:</p> <ul style="list-style-type: none"> - Check the rectifier - Replace the defective rectifier <p>Measure the DC voltage:</p> <ul style="list-style-type: none"> - Overexcitation 90 V (approx. 1 sec.) holding voltage 45 V (tolerance $\pm 10\%$) <ul style="list-style-type: none"> ■ Check the coil for fault between turns and short circuit to ground. ■ If the rectifier defect occurs again, replace the brake even if you cannot find any fault between turns or short circuit to ground. The defect may occur later during heating-up.
	Air gap too big	Replace the brake (chapter 7.3)
Brake disc cannot rotate freely	Air gap "s _{air} " too short	<ul style="list-style-type: none"> ■ Check the air gap "s_{air}" and replace the brake, if necessary. ■ Check the thickness of the brake disc and replace the brake disc, if necessary. ■ Check the movability of the brake on the guide sleeves and, if necessary, replace the guide sleeves.
Brake cannot be released with manual release	Wrong setting of manual release	Replace the brake and complain about the manual release setting to the manufacturer.
Microswitch furnishes wrong signal despite correct function of the brake	Wrong wiring of microswitch	Check and correct the microswitch wiring.
	Microswitch defective or set incorrectly	Replace the brake and send the defective brake to the manufacturer.

8 Troubleshooting and fault elimination

Error	Cause	Remedy
Voltage too high	Supply voltage too high	Adapt the coil voltage to the supply voltage.
	Rectifier defective	Replace the rectifier
	Bridge rectifier used instead of bridge/half-wave rectifier	Replace the bridge rectifier by a bridge/half-wave rectifier.
Voltage too low	Supply voltage too low	Adapt the coil voltage to the supply voltage.
AC voltage is not mains voltage	Fuse is missing or defective	Select a connection with proper fusing.
	Wrong wiring of microswitch	Check and correct the microswitch wiring.
	Microswitch defective or set incorrectly	Replace the brake and send the defective brake to the manufacturer.

9 Disposal

Protect the environment! Packing material can be recycled.

What?	Where?	
Transport material	Pallets	
	Return to the manufacturer or forwarder	
Components	Packing material	
	Cardboard boxes to waste paper Plastics to plastics recycling or waste material Reuse or dispose of wood wool	
	Mounting plate, armature plate, flange, sleeves	Steel
Seals, friction lining, coil housing	Hazardous waste	



Notes



Notes



Notes



INTORQ – Sales and service around the world

INTORQ customers can reach us at any time and from anywhere in the world. Our Key Account Sales Team looks after key account customers and project business.

In addition, we co-operate with Lenze's global sales organisation.

You can contact us via Lenze Service by calling the 24-hour helpline (008000 24 46177).

INTORQ GmbH & Co KG

Postfach 1103
D-31849 Aerzen

Wülmser Weg 5
D-31855 Aerzen

☎ +49 (0) 51 54 95 39-01

✉ +49 (0) 51 54 95 39-10

E-mail info@intorq.de

www.intorq.de

INTORQ

setting the standard

www.intorq.de