

V-drum Tips

Pd-8 custom fixing screw

1. Remove the 3 screws, and the metal cover and the pipe.
2. You need to buy an M6 eye screw, a convenient flat washer and an M6 wing nut.
Make sure the eye screw is big enough to fit on the L-rod you are using.
3. The outside dimensions of the screw are too big to fit in the plastic cage of the pad. Therefore you need a metal rasp. Remove as much material as necessary.
Check if the eye screw matches horizontal in the plastic cage and is still moveable.
4. Stick the screw from the inside through the hole of the metal part, attach the washer and the wing nut.
This is basically the same technique as used on the PD-125 pad from Roland.
5. Assemble the parts and screw everything together.
6. And finally mount the pad.

You can also use this solution for the PD-80 and the PD-85 pad; they are constructed in the same way.