

CMP17/A KISS Anti-Fray Iron On Sock Reinforcements

We recommend using a flat, hard surface covered with a thin, clean, cotton towel (like a kitchen towel) for the ironing part of this process. You will also need a consumer clothing iron and a 3/4" hole punch.

Make sure that the bottom surface of the iron is clean and there is no water in the iron's reservoir. Producing steam during this process could inhibit bonding.

- 1) Place shiny side of small sheet on sock
- 2) Cover with large sheet shiny side up
- 3) Iron over large sheet medium/ hot about 20 seconds
- 4) Remove large sheet
- 5) Peel off and discard small sheet. The clear reinforcement will adhere to sock.
 - Reuse large sheet
 - Do not iron near printed label on sock
 - Punch hole through reinforcement with 3/4 inch hole punch