



COAXIAL CABLES - CABLE TRIM SPECIFICATION

MSW -CX1032 RG178, RG196/U

ASSEMBLY INSTRUCTIONS



1


- 1-1 Place boot and ferrule onto the cable
- 1-2 Strip the cable as shown



Body


2

- 2-1 Disperse Shielding layer of the cable.



3

- 3-1 Position the body onto the cable
- 3-2 Solder the contact
- 3-3 Push the ferrule onto the body.



4

- 4-1 Crimp ferrule with 2.54 mm Hex Crimp Die
- 4-2 Pull the boot over the ferrule