

INSTALLATION INSTRUCTIONS

Thank you for selecting WT Shade as your shading solution! We hope you will be pleased with the outcome of your project, and we strive to do everything in our power to make that so. If you have questions regarding our Shading Systems and Accessories, please **visit WTShade.com for detailed information**, or call:

WT Shade Customer Service:
(877) 294-3580
Monday - Friday
8:30AM - 5:00PM



Before you Begin

Ensure the area is prepared and ready for shade installation: Installation should never occur if the area is not fully complete. Additional installations such as wall paneling, pocket installations, painting and other types of finishes must be complete prior to shade installation. The area should be clean and free from dust and debris. We recommend cleaning the glass of the window prior to installation to ensure that no cleaning solutions will come into contact with the shade fabric. Wood blocking is required for all installations and should have been installed prior to finishing the walls.

Locate all necessary hardware and boxes: Brackets, bead stops, accessories, motor controls, power supplies, and other small items may be shipped in a separate box from the shades. Check the packing slip to locate the number of boxes received and ensure that all the hardware is present before beginning.

NOTE: CEILING POCKETS MUST BE INSTALLED PRIOR TO INSTALLING SHADES.
For instructions on Pocket installation see step 4. Accessory Installation.

Tools you will need to provide:

- Recommended screws: #10 or #12 Hex Head Screws. Jamb mount applications will require pan head screws
- Washers
- Electric screw driver/drill with appropriate tips
- Hand-held screw driver with Phillips head bit
- Measuring tape
- Level
- Combination Pliers
- MotoRise Only - Programming tools (i.e. Motor Controls, Limit Setting Tools & Switches, etc.)
- MotoRise Only - Wiring

