



DACF 1.03 SOFFIT CROSS SECTION & CONTROL JOINT DETAIL

DECOPLAST ACF SOFFIT - 6/1/2016

NOTES:

1. CONTROL JOINTS ARE REQUIRED AT THE FOLLOWING LOCATIONS:
(REFERENCE CONSTRUCTION DOCUMENTS FOR SPECIFIC LOCATIONS)
 - A. NO MORE THAN 32 LINEAL FT IN ANY DIRECTION
 - B. AT DISIMILAR SUBSTRATES AND FRAMING TRANSTIONS
2. DOUBLE STUDS MAY BE REQUIRED AT CONTROL JOINTS OR WHERE NEEDED TO PROVIDE FASTENING BASE FOR THE SUBSTRATE BOARD JOINTS

Disclaimer: The design, specifications, and construction shall comply with all local building codes and standards. Decoplast installation guidelines are for general information and guidance only and Decoplast specifically disclaims any liability for the use of this design, and for design, engineering, or workmanship of any project. The assembly shall be designed to prevent condensation within the assembly. The designer and the user shall provide final drawings and specifications. Products shown other than those manufactured by Decoplast are shown for clarity of the Decoplast product only. Contact the manufacturer of such other products for installation instructions.