

Day 6 Seat Strut Installation

1: Adjust seat to proper height.

2: Remove both rearward bolts from the underside of the seat pan and attach U brackets using the same bolts.

3: Attach seat strut clamp to threaded insert on seat stay with long 5mm bolt. Do not tighten. Slide seat strut into seat strut clamp.



4: Swing seat strut up and attach to U bracket using short bolt and nylok nut.



5: Securely tighten all bolts.

NOTE: If you are shorter, you may need to cut off the end of the seat strut or it may interfere with the derailleur or kickstand. Cut to length, smooth the end with a file, and touch up with a black permanent marker or spray paint.



Kit Includes:

- 2- Struts
- 2- U brackets
- 2- Long M5 bolt
- 2- Short M5 bolt
- 2- Nylok nuts
- 2- Seat strut clamps

Warning:

Failure to use seat struts voids all warranties.