

# Basket Strut Installation to Front Fork

Place aluminum spacer between the Basket Strut and the threaded tab on the Day 6 fork.

Insert 5mm x 3/4" bolt through strut and spacers and screw into threaded tab.

Follow manufacturer's instructions for the rest of the installation.



Questions? Call 406/570-1927