

Owner's Instructions



Part No. : E8140403

ZillaReel™ Retractable Extension Cord Reel



IMPORTANT!

Read all instructions and warnings before operating this product.
SAVE THESE INSTRUCTIONS!

WARNING!

Never open the reel case. The internal spring system is under high tension; damage or personal injury may result.

Warnings

- DO NOT USE IF DAMAGED. Inspect thoroughly before each use.
- Make sure the power source is compatible with the voltage rating. Power source must have protection against short circuit and overload.
- FULLY INSERT plug into outlet. Do not remove, bend or modify any metal prongs or pins of plug.
- DO NOT USE WHEN WET. Keep connection away from water. Do not expose to rain or moisture.
- AVOID OVERHEATING. Do not expose to extreme heat or flame. Uncoil cord and do not cover it with any material.
- Power cord should not run through doorways, holes in ceilings, walls or floors. Keep the work area clean.
- Do not drive, drag or place objects over cord. Keep children and pets away from cord.
- Do not disconnect power source by pulling on cord or use excessive pull force on cord assembly.
- Do not disassemble any parts for any reason.
- Always pull cord from reel by grasping the cord itself instead of the plug.
- Never remove, tamper with or cut the safety devices fitted by the manufacturer.
- Do not use the reel in damp or wet conditions.

Cord Ratings & Specifications

Ratings:

- Max Watts: 1560W
- Max Amps: 13A
- Max Voltage: 120V
- Max Hz: 60Hz

Specifications:

- 40' output
- 5' input
- 14/3 AWG
- SJTOW

Use:

- Indoors
- Dry Locations



Installation on Wall or Ceiling

- Only qualified electricians can install/service this cord reel.
- Use appropriate mounting hardware to secure bracket to the wall or ceiling.
- Adjust the cable stopper to the suitable position when required.

Maintenance

Cleaning the Cord:

Regular cleaning of the cord is an important part of ensuring your cord reel stays in proper working order:

- Cord should be cleaned using a warm, damp cloth.
- Detergents or solvents should not be used on the cord as damage to the cord or reel may occur.

Connecting & Disconnecting Tools:

- Tools connected to the cord should never be used to pull the cord. Always pull the cord itself.
- Remove tools from extension cord after use. Do not allow tools to hang from cord.

Operation

- Check reel for correct operation by slowly pulling out the cord. A "clicking" sound should be heard every 1ft. of cord.
- To latch the reel, pull out the cord and allow it to retract after hearing the first, second or third "click".
- To unlatch, slowly pull out the cord until the "clicking" noise stops, then let the cord retract until the cord stopper rests against the cord guide.
- To avoid damage to the reel, always hold on to the cord while it is rewinding.

Environmental Protection

Waste electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.

WARRANTY

LEGACY MANUFACTURING COMPANY ("LEGACY") warrants that this equipment will be free from defects in material and workmanship for a period of one (1) years from the date of purchase, under normal use.* LEGACY'S sole obligation under this warranty is limited to replacing or repairing, free of charge, any equipment that proves to be defective under normal conditions and use according to the recommendations of LEGACY. To obtain repair or replacement, the equipment must be shipped to a LEGACY authorized Warranty and Service Center during the warranty period, transportation charges prepaid, with proof of date of purchase. In the event of repair or replacement, the warranty period shall not be extended beyond the original warranty period.

© Copyright 2017, Legacy Manufacturing Company

All rights reserved. Any unauthorized use or copying of the contents or part thereof is prohibited. This applies in particular to trademarks, model denominations, part numbers and drawings. Use only authorized parts. Any damage or malfunction caused by the use of unauthorized parts is not covered by Warranty or Product Liability.