

24-Hour
Emergency: 833.837.2665



Office: 972.277.4500

AUTOMATIC SETTING FOR R/S INDUSTRIAL AMMONIA REFRIGERATION CONTROL VALVES

S5A	OUT for Automatic	S7A	OUT for Automatic	S4A	IN for Automatic
S6N	OUT for Automatic	S8F	OUT for Automatic	S5F	OUT for Automatic
S9F	IN for Automatic	S4W	OUT for Automatic	S9W	OUT for Automatic
A4A	IN for Automatic	CK2	OUT for Automatic	CK5	OUT for Automatic

A4AD - When ENERGIZED, set for LOW pressure.
When DE-ENERGIZED, set for HIGH pressure. Stem IN for Automatic.

THREE WAY RELIEF VALVE OPERATING INSTRUCTIONS

PARKER / YORK	Facing Stem: When stem is IN, Right valve is closed When stem is OUT, Left valve is closed
SHANK	Facing Stem: When stem is IN, Port #2 is open When stem is OUT, Port # 1 is open
FRICK / HENRY	Facing Stem: When stem is IN, Nearest valve is open When stem is OUT, Farthest valve is open