


# Microcosm Launch Rail – Launch Lugs



## Machine two launch lugs

- Attach one to the C.G. of the rocket.
- Attach second to bottom end of rocket.

Launch lugs do not need a separate attachment bracket and can be attached directly to the rocket.

Lug sides remove to allow side mounting of rocket to launch rail.

