



Model XD-88

XD-88: X-Ray Waveform Sensor
with or without a Cable

Features

- Two-year warranty
- Optional BNC to BNC cable
- Weighted enclosure
- Compact design

Typical Applications

Use a BNC-to-BNC cable to connect the XD-88 directly to a standalone oscilloscope or a USB module for a computer oscilloscope program.

- Measurement of exposure time
- Verification of x-ray operation
- X-ray calibration
- Quality assurance
- Documentation
 - » Troubleshooting and repair of x-rays
 - » Exposure time calibration
 - » Rectifier problems
 - » Loading characteristics
 - » Shutter calibration



Electronic Control Concepts

PO Box 182, 1160 HWY 50
Milford, Ohio 45150-9705 USA
Phone: 800-VIP-XRAY

Fax: 513-248-2402

sales@eccxray.com | www.eccxray.com

A Division of US Nuclear Corp

www.usnuclearcorp.com