



**EXAMPASSED.NET**

**REAL SPY GEAR ALL IN ONE PLACE!**



**INSTRUCTION MANUAL**


**HD SPY MICRO WI-FI CAMERA WITH GLOBAL RANGE CONTROL**



**RECOMMENDED SPY MODE.**

**GLOBAL  
WORLDWIDE  
RANGE**





P2P network camera  
Product Manual

P2P network camera  
Easy to use manual

scan the code,  
download the client software



Live CD:<http://www.scc21.net>

Mobile phone software installation  
Iphone / ipad and Android mobile phone  
software to download and install




1. Iphone system: APP store search P2Pcam viewer or 9527
2. Adroid system: Google Market Search P2Pcam viewer or 9527

Get detailed instructions  
As shown: Click the red inner circle? No, you  
can obtain more detailed operating instructions



## Hardware Installation

### Connect network cameras to the network



1. The network camera power supply is connected properly
2. The cable network camera is connected to the router
3. After completing steps 1 and 2, the device's hardware connection has been completed

1

## Software download and installation

Software download and installation: Open a browser enter the URL: <http://www.scc21.net> download and install the corresponding software system




Google software market with the Apple APP STORE software search for "9527" can get network camera platform software The platform supports the following systems



2

3

### Open SYSM Monitor software Watch Video



LAN equipment automatic on-line

Internet use outside the network

1. Click on the desktop shortcut to open SYSM Mitor PC client software
2. Click on a LAN, such as computer equipment and under the same router,the device automatically on-line, click to watch
3. Internet viewing, click on the Internet a list of the input device body username, password account login remote device to watch video success

5

### Set up a wireless wifi

Enable device wireless wifi function



1. LAN list: Right-click on the need to set up a wireless wifi device - Select Set Wireless
2. Start wifi settings - Select Search - select the appropriate network and enter the wireless password - OK
3. Equipment automatic restart - unplug the network cable - wifi equipment automatically enable wireless function - Wireless wifi is set up

6

7

MORE INSTRUCTIONS AVAILABLE AT

[www.exampassed.net](http://www.exampassed.net)

