

Sensor Node (SN) Quick Start Card



The following checklist can be used as a quick field reference guide for rapid system deployment.

1. Mount the battery housing to the mast (if required)
2. Open the battery housing, connect the battery, close the battery housing
3. Mount the Sensor Node enclosure with the provided mounting hardware on the collapsible mast
4. Raise the mast to the required height
5. Open the Sensor Node logger enclosure
6. Open the front panel
7. Install a newly formatted microSD card into the microSD card socket
8. Close the front panel
9. Plug in either the battery housing, if fitted, or an external power supply
10. Turn on the logger via the ON/OFF push button switch.
11. If necessary, connect to via the USB port and configure the desired scan interval
12. Close the enclosure cover

Central Receiving Unit (CRU) Quick Start Card

THINGY:AQ

The following checklist can be used as a quick field reference guide for rapid system deployment.

1. Mount the CRU housing to the mast using included hardware
2. Connect the antenna cable to the antenna
3. Mount the antenna onto the top of the mast
4. Raise the mast to the required height and tighten the mast connection
5. Connect the antenna cable to the antenna cable connector on the bottom of the CRU
6. Open the CRU enclosure
7. Unscrew the two screws on the righthand side of the front panel
8. Open the front panel of the logger and connect the battery's mating XT30 connectors together. When the battery has been connected, a red LED on the solar charger will be illuminated.
9. Install a newly formatted microSD card into the microSD card socket
10. Close the front panel and screw in the two screws on the righthand side of the panel
11. Plug in either the solar panels, if fitted, or an external power supply
12. Turn on the CRU logger via the ON/OFF switch on the front panel