

VX-38	
Part #	Part Description
69020	Ab Crunch Strap
58150	Ab Pulley assembly- with pulley
58140	Ab Pulley Bracket- without pulley
57900	Access Door (painted)
2.5AO	Add-on plate- 2.5 pound
5.0AO	Add-on plate- 5 pound
60760	Adjustable Pulley Assembly with pulley and hardware (main column)
60580	Adjustable Pulley Bracket- no pulley or hardware (main column)
21770	Adjustable Pulley weldment (main column)- no pulley/hardware (uses 22030 bolt)
54760	Bar/Shaft- for press adjust- moves into notches (uses 54770 e-ring)
53770	Bar/Shaft- pivot for lat hold down
54150	Bar/Shaft- two are used inside row/ab seat back adjustment
11920	Bearing- freeway for most pivot points, used with #13790 button head bolts
38770	Bench Leg Stop Bar- used in leg/ab station
21920	Bolt- 1/4-20 X 1.25 hex for press guide rods
22030	Bolt- 1/2-13 X 6.00 for adjustable pulley in main column
13790	Bolt- 1/2-13 X 1 button head for most freeway bearing pivot points
20850	Bolt- 1/4 X 20 X .75 for mounting upholstery
63330	Bolt- 1/4-20 joint connector to mount low pulley (uses #63340 nut)
23300	Bolt- 3/8-16 X 1.25 Hex, Zinc
52910	Bolt- 3/8-16 X 1.5 for columns, pulley assemblies (double, single, adj., etc.)
12760	Bolt- 3/8-16 X 1.75 for most pulley assemblies & column caps
55870	Bolt- 3/8-16 X 1/2 hex w/flange for wt. guards & upper stack support (14 required)
29190	Bolt- 3/8-16 X 3 for top plate
55860	Bolt- 3/8-16 X 3/4 blk hex with flange for frame (22 required)
14210	Bolt- 3/8-16 X 4 for most adjustable pulleys
27330	Bolt- 5/16 X .625, 1/4-20 shoulder for row cable retainer
17080	Bolt- 5/16-18 X 1.5 for guide rod threaded inserts
43230	Bolt- 5/16-18 X 3 SHC for seat lock
63590	Box #1 VX38- Large
63600	Box #2 VX38- Small
VXPC-CLR	Boxed Rear Press Column (Completer)
20000	Bracket- for double-moving pulley (2 required)
55070	Bracket- part of press adjustment assembly that goes into notches
59120	Bumper- double stem for calf/row block
42220	Bumper Tube- for butterfly arm pawl
47590	Bumper, Row/Leg Press Dwn Stop
57670	Bumper weight stack (two required)
54130	Bumper/Plug-3/4 inch stem for b/fly cam, leg/ab seat & bench
11450	Bushing- bronze for butterfly cams
52560	Bushing Cap- left-side , secures press arm into press housing OBSOLETE
52550	Bushing Cap- right-side , secures press arm into press housing OBSOLETE
66930-CLF	Bushing Cap (right or left) secures press arm [uses 14500 (4) & 15890 (2)]
43780	Bushing- nylon for butterfly arm
24160	Bushing- nylon, for pivot pulley
51600	Bushing- press arm (plastic ring version), press arm pivots on these
20620	Bushing- weight plate (all) & top plate
43050	Butterfly Arm assembly- left-side for VX/4800/3800/1850/4850/3850
43040	Butterfly Arm assembly- right-side for VX/4800/3800/1850/4850/3850
43070	Butterfly Cam assembly- left-side
43060	Butterfly Cam assembly- right-side
47930	Cable- 10-inch extension for low pulley (10EC1)
20910	Cable- ab crunch station- 126" long
28840	Cable- butterfly station- 70.84" long
21930	Cable- high pulley- 111.7" long
20920	Cable- leg extension- 116.0" long (12.5" stripped)

VX-38	
Part #	Part Description
59850	Cable- low pulley set with 10-inch extension
57810	Cable- low pulley without 10-inch extension 130.45" long
55090	Cable- press adjustment inside press arm assembly
40980	Cable- row station- 28.18" long
57310	Cable Set- VX38/3850 complete
22120	Cable Stop- slotted for leg extension cable (set screw #22280 sold separately)
17160	Cable Tie
43480	Clevis Pin/Bar/Shaft- 2-5/8 X 1/2- leg/ab seat back pivots on this (uses 53790 c-ring)
15920	Clip- accessory attachment used to anchor cable in row column
55910	Clip- plated for row seat back adjustment
CGPB	Close Grip Press Attachment Set- Black- allows close grip exercises on press arms
CGPCP	Close Grip Press Attachment Set- Classic Pewter- for close grip exercises on press arms
CGPSS	Close Grip Press Attachment Set- Sterling Silver- for close grip exercises on press arms
CGPW	Close Grip Press Attachment Set- White- allows close grip exercises on press arms
65570	Close Grip Press Attachment- right-side
65580	Close Grip Press Attachment- left-side
50220	Column Cap- for main column
21080	Column cap- row column
51590	Column Cap- rear/press/completer column
12340	Cotter Pin- 3/16 X 1.5 inch for butterfly arms/cams (used w/#62850 washer)
55080	Cover- plastic, for press housing
21520	Cover Plate- for main column upper stack
21510	Cover Plate- for row/ab upper stack
CCF???	Cross Chest Fly Option Kit- converts standard butterfly to cross chest version
63540	Curl Bar assembly- (straight) BLACK only
14180	Double Moving Pulley assembly- with pulleys & hardware
54770	E-Ring- 1/4 external used with 54760 shaft
53790	E-Ring/Crescent-Ring- VFT pulley arm & guide pulley, press & row levers
50160	Floor Piece/Board- VX38/4850 triangular
10340	Foam Roller
49180	Frame- main triangle (also used on 4850)
13240	Grip- 4 Inch for inner section of lat bar
61910	Grip- 6-inch "SS Cap" for camberd bar & VX row arm (2 per side, total of 4)
61890	Grip- 8-inch "SS Cap" version for VX/1650 accessories
54740	Guide- nylon, for cable press arm cables
21980	Guide Rod- 55.80 inches for press station, includes end cap
55400	Guide Rod- 55.80 inches for row station with tube connector, bolt & spacer
55430	Guide Rod- 74.74 inches, includes tube connector, spacer & bolt
62000	Handle- Single Grip 8-inch strap
63630	Hardware Kit- VX38
61880	Knob- bench adjust and Lat hold down grip (yellow)
28020	Label- "Manufactured by..."
28010	Label- "Warning..." for wt. guard
61720	Label- 10-inch Silver Vectra (stack column)- pairs with VX diamond label
43820	Label- left-side squat
43830	Label- right-side squat
63260	Label- VX Diamond- pairs with 10-inch silver Vectra label
60600	Label- weight stack number sheet for standard stacks
53750	Label/Decal- VFT/VX38/1650/1600 "Leave in place..."
62640	Lat Bar assembly
62680	Lat Hold Down assembly
52980	Lat Hold Down Latch weldment
61730	Lat Hold Down Pad/Roller (2 required)
62160	Lat Hold Down weldment
53930	Latch/Lever- squat attachments (uses 54010 spring pin)
54080	Leg Develop weldment (without pads)

VX-38	
Part #	Part Description
54090	Leg Developer- with contoured leg pads
62690	Leg/Ab Seat Bottom assembly- with seat lock strut, but not upholstery
62710	Leg/Ab Seat Handle assembly
56020	Leg/Ab Station VX/3850/4850 weldment
57160	Leg/Ab Station VX38/3850/4850 assembly
54050	Leg/Ankle Strap
52230	Lever- press & row seat adjust (requires #53790 crescent ring)
40210	Loctite 242- 50 ML
29040	Low Pulley Bracket- 6 Inch without pulley
61500	Low Row/Calf Block
63610	Main Column assembly- VX38
56270	Main Column weldment- VX38/3850/4850
56910	Manual- 3850/4850 (part 1 only for 4850) - OBSOLETE 11/06
67440	Manual- VX38
17340	Nut- 1/2-13 hex jam for VX38/3850/4850 adjustable pulley
13740	Nut- 1/4-20 for row arm cable retainer pivot & press guide rods
63340	Nut- 1/4-20 joint connector- used to mount low pulley (used w/#63330 bolt)
58920	Nut- 10-32 used as jam nut on press cable adjustment screw
10600	Nut- locking 3/8-16 Hex for most pulley assemblies
53920	Pad- contoured for leg developer (uses 2 #14500 screws)
65870	Pad- Squat Shoulder
57570	Padding- center of curl and lat bar, etc. (1 per bar)
46000	Panel Fastener Clip/plug- used to secure column caps
28151	Pawl- for butterfly arms
54800	Pin- row seat lock in seat back adjustment
54810	Pin- row seat pivot in seat back adjustment
28930	Pin/Dowel- .25 DIA X 1 for butterfly arm pawl
27990	Plug (Christmas tree)- black plastic for cable retainer openings
49490	Plug/Cover- VX38/4850 press pivot arms
56880	Poster- VX38/3850/4850/1850
55770	Press Arm/Handle assembly (Replaced with VX-18/38 press arm 63580-clr)
60420	Press Housing assy- VX38/3850
57280	Press Lever assy- LOWER VX38/4850
60460	Press Lever assy- UPPER VX38/4850
10580	Pulley- 4.5-inch
25220	Pulley- 6 inch
54190	Rack Housing- used in row seat back adjustment- has notches (painted)
63170	Rear/Press/Completer Column assembly
20660	Retainer- for cable on leg developer and top of weight stack
46920	Retainer- for row arm cable
48340	Roll Pin- 5/16D X 1.25 used on leg developer
27910	Roll Pin- 5/32D X 7/8L for swivel pulleys, butterfly arm pawls, etc.
63450	Row Arm assy- chest supported VX
63440	Row Arm- weldment
42450	Row Seat Lever
63620	Row/Ab Column assembly
63620	Row/Ab Column assembly- VX38
56340	Row/Ab Column weldment- VX/3850/4850
51680	Safety Tread- for calf/row block
14500	Screw- 1/4-20 X .50 phillip for leg developer pads & press bushing caps
22280	Screw- 1/4-20 X .25 set screw for slotted cable stop
15890	Screw- 1/4-20 X 1.25 OPH for bushing cap tensioning
53710	Screw- 10-32 X 1.25 phillip for press adjust cable tension (uses #58920 jam nut)
54270	Seat Back weldment- row station, painted
54220	Seat Link- used in row station seat back adjustment, painted
62700	Seat Lock Strut/Latch assembly

VX-38	
Part #	Part Description
60610	Selector Pin
20630	Selector Shaft- standard for 210 and 260 pound weight stacks (20 hole)
43570	Shaft- .5 DIA X 8 for row station upper back pivot
43580	Shaft- .5 DIA X 8.5 for leg developer/seat pivot (seat pivots on this)
42560	Shaft- for row/leg seat back pivot
17750	Shaft Retainer- .5 shaft (large) for most shafts
60510	Single Moving Pulley assembly- with pulley & hardware
60500	Single Moving Pulley bracket- without pulley
16520	Spacer- .81 X .52 X .5 nylon for guide rods
28200	Spring- butterfly arm pawl
27900	Spring- extension 1.25FL for lat hold down, press handle & seat adjust
22960	Spring- extension 8.4 x 1" dia. for press station weight reduction
17930	Spring Pin- .25 X 2.75 for lat/leg hold down & press handle
54010	Spring Pin- 5/32 X 1-1/4 for squat latch
53990	Spring- squat attachment latches
41430	Squat Attachment- left-side Obsolete 01/07
41440	Squat Attachment- right-side Obsolete 01/07
66400	Contr'd Squat Assy- Left Side
66410	Contr'd Squat Assy- Right Side
55970	Tape- UHMW 1 X .015 X 2 used in seat back adjustment
28040	Tie- 4 inch plastic
60700	Top Plate- weight stack
49090	Touch-Up Paint- Black bottle
20800	Touch-Up Paint- Black can
49100	Touch-Up Paint- Classic Pewter bottle
15520	Touch-Up Paint- Classic Pewter can
63360	Touch-Up Paint- Sterling Silver bottle
63350	Touch-Up Paint- Sterling Silver can
49080	Touch-Up Paint- White bottle
20790	Touch-Up Paint- White can
43030	Trim Strip- for ab pulley
54100	Trim Strip- VX-38/VX-18 leg developer
22050	Trim Strip- for weight guard (71" per guard- generic#- not for specific location)
43160	Trim Strip- used at leg seat lock
22040	Tube Closure/End Cap- 1 inch DIA X 16GA for press station guide rods
53940	Tube Closure/End Cap- 1 inch round for squat attachments
15780	Tube Closure/End Cap- 1 X 2 X 10-14GA used on press levers
42250	Tube Closure/End Cap- 1.75 inch for end of press handle
60470	Tube Closure/End Cap- 1.75 inch round external for butterfly arms
51330	Tube Closure/End Cap- round closure/retainer for foam rollers (all)
11340	Tube Connector- 5/16-18 X 1" threaded insert for guide rods
62610	Upholstery- bench seat back VECTOR bench ONLY (6-hole)
43110	Upholstery- butterfly arm pad BACKING BOARD ONLY- left side
43100	Upholstery- butterfly arm pad BACKING BOARD ONLY- right side
43090	Upholstery- butterfly station arm pad- left side
43080	Upholstery- butterfly station arm pad- right side
63030	Upholstery- full set with VECTOR bench upholstery (6-hole seat back)
55650	Upholstery- full set WITHOUT bench- VX38/1850/3850/4850
59200	Upholstery- seat back butterfly station
51140	Upholstery- seat back leg/ab station
39090	Upholstery- seat bottom bench
61330	Upholstery- seat bottom butterfly station
43210	Upholstery- seat bottom leg/ab station
63020	Upholstery- VECTOR bench full set
21230	Upper Stack Support assembly- with pulley & hardware
21950	Upper Stack Support- without pulley & hardware

VX-38	
Part #	Part Description
62760	Vector Bench assembly w/o upholstery (components listed on separate sheet tab)
VB???	Vector Bench- complete/boxed
46970	Washer- .688 X .39 black nylon for taking up slack in leg/ab seat assembly
49310	Washer- 1.62 X 1.14 X .065 uses with press pivot levers
12620	Washer- 7/8-16 X 1/2 X 14GA
26130	Washer- neoprene bumper for top plate- standard
26140	Washer- neoprene, top plate at press station ONLY
62850	Washer/Bushing- 1-1/2 X 1 X 14GA for b/fly arms/cams (uset w/#12340 cotter)
60680	Weight Plate- 10 pound
60690	Weight Plate- 15 pound
60710	Weight Plate- box of five 10 pound plates
60720	Weight Plate- box of five 15 pound plates
22190	Weight Stack Guard assembly (requires 3)