

ES25 EFFLUENT CHAMBER VOLUME TABLE

Liquid Depth	Gallons Per Inch	Gallons In Chamber	Liquid Depth	Gallons Per Inch	Gallons In Chamber	Liquid Depth	Gallons Per Inch	Gallons In Chamber
82 ¹	12	1258	55	20	814	27	17	273
81	12	1247	54	20	795	26	16	356
80 ²	12	1235	53	20	775	25	16	340
79	13	1223	52	20	754	24	16	224
78	13	1210	51	20	734	23	15	209
77	14	1197	50	20	714	22	15	193
76	14	1183	49	20	694	21	14	179
75	15	1169	48	20	674	19	13	164
74	15	1154	47	20	653	18	13	151
73	16	1139	46	20	633	17	12	137
72	16	1123	45	20	613	16	12	124
71	16	1107	43	20	593	15	11	112
70	17	1091	42	20	573	14	11	100
69	17	1074	41	20	553	13	10	89
68	17	1058	40	20	513	12	10	78
67	18	1040	39	20	493	11	9	68
66	18	1023	38	19	474	10	8	58
65	18	1005	37	19	454	9	8	49
64	18	987	36	19	435	8	7	41
63	19	968	35	19	416	7	6	33
62	19	950	34	19	397	6	6	26
61	19	931	33	18	379	5	5	20
60	19	912	32	18	361	4	4	7
59	19	893	31	18	342	3 ³	3	3
58	20	873	30	18	325	2	0	0
57	20	854	29	17	307	1	0	0
56	20	834	28	17	290			

¹ to invert of effluent filter. Above this level, water will fill remainder of the tank's above-board volume (715 gallons total above normal operating level). ² to invert of gravity outlet. ³ the pump shelf is 3" off bottom of tank