



4590 N 11000W Rd
Bonfield, IL 60913
(815) 426-2330

Retrofit Bushing Instructions:

1. **-Swapping out bushings on stalk stompers with a chain** – Keep shoe attached to mount on the head. Compress shoe so chain has slack. Unbolt chain from arm (2" arm that runs down the shoe). Shoe should now be able to swing freely without any down pressure.
-Swapping out bushings on stalk stompers that do not have a chain – Keep shoe attached to mount on the head. Compress shoe so arm is not resting on stop. Remove the 2 bolts from stop in front of the shoe and remove stop. Shoe should now be able to swing freely without any down pressure.
2. Remove the shoe from the mount that is bolted to the header
3. Unbolt grease bolt and remove
4. Remove arm (2" arm that runs down the shoe) from the bracket that attaches the shoe to the mount
5. Remove the existing bushings and spring from arm (note position of exterior bushing's flat area).
6. Insert new interior bushing and nylon bushings into exterior bushing and assemble onto arm with spring. Put arm back into the bracket that attaches the shoes to the mount and bolt together using new hardware provided.
7. **- Swapping out bushings on stalk stompers with a chain** – Place shoe back into mount on head. Using leverage from the head, compress shoe and bolt chain back onto arm.
- Swapping out bushings on stalk stompers that do not have a chain – Place shoe back into mount on head. Using leverage from the head, compress shoe and place stop back into position and bolt into place.
8. Check and make sure all bolts and nuts are tight.